# QUICK WIRING for: FHD4G, FHD4W & FHD4W Mobile Video Solutions

#### **Power Harness Cable**

Wire Color	Function	Plug Pin
Brown	+12v Battery (Fused 1.5A)	Pin # 1
Blue (Trigger -ACC)	+12v Ignition On	Pin # 2
Black	-12V Ground	Pin # 3


### Download & Read: SD4D User Manual

http://www.americanbusvideo.com/CUSTOMER-FTP/FHD4/User%20Manual%20&%20Suppliments/

### Manufacturer Provided SD4D Dedicated Video Player

http://www.americanbusvideo.com/CUSTOMER-FTP/FHD4/DVR\_Player%20setup\_/ Select "Video Player", Select the download version you wish

4CH SDI 1080P



## SENSOR Interface definition:

1	Canbus+	11	Alarm	input	1
2	Canbus-	12	Alarm	input	3
3	RS485+	13	Alarm	input	2
4	RS485-	14	Alarm	input	4
5	Alarm outputCOM1	15	Alarm	input	GND
6	Alarm outputCOM1	16	Alarm	input	GND
7	Alarm outputCOM2	17	Alarm	input	5
8	Alarm outputCOM2	18	Alarm	input	7
9	Alarm input GND	19	Alarm	input	6
10	Alarm input GND	20	Alarm	input	8

## EXTEND Interface definition:

DC12V OUT+
DC12V OUTAudio input
Audio output
RS232 (RX)
Video output
RS232 (TX)
Video/Audio GND



### Important User Information

HD-SDI Cable Connection & Sourcing Warning \*\*\* Important Notice Regarding Warranty

Do not connect any camera cable to the FHD4G, FHD4W or FHD4C High Definition DVR while the DVR is powered up, or while any of the LED indicator lights are illuminated, or this action will VOID the Warranty of the FHD4G, FHD4W or FHD4C DVR.

HD-SDI signal speed is 1 - 1.5 GHz/s and compared to analog signal of 550TVL 270 MHz/s it is 4 - 5 times faster so the need for a coaxial cable is important. HD-SDI dedicated coaxial cables do not exist commercially yet, so the existing coaxial cable with impedance of 75ohm coaxial cable must be used for installation and when there is a break or BNC connector then the additional elements of external shock must be cautioned while reconnecting the camera cables or camera extension cables.

#### **Required Camera Cable Connection To DVR Procedure:**

- Remove all power from the DVR,
- Check the LED indicator lights to make sure they are not illuminated,
- Connect Camera Extension cable to the camera optical head,
- Then & only then connect camera Extension cable to DVR.
   Those who fail to read this warning, and or fail to follow "Required Camera Cable Connection To DVR Procedure" will be liable for all cost of repairs to the DVR as well as all non-warranty related shipping costs.

### **American Bus Video**

2545 Valley Ridge Drive Cumming, GA 30040 (770) 263-8118 (770) 887-5944 Fax

www.AmericanBusVideo.com sales@AmericanBusVideo.com