Read Me Notes:

The system has 2 cameras, GPS and G-Sensor. Unzip archive, or copy folder to your windows desktop. It is a folder with 2 AVI files.

Download the newest version of AVPlayer v2.3.5 at: http://www.americanbusvideo.com/CUSTOMER-FTP/SD4mX/Video%20Player/ (This is n now the only version that has the corrected Google map fix)

Open the newest version of AVPlayer v2.3.5 Browse for the folder named: "View with AVPlayer G-Sensor & GPS"

Camera 1 is ExCam so it is an external camera with no mic.

You must select Audio Channel 2 for audio to be heard as the AVPlayer defaults to Audio Channel 1.

For G-sensor charting remember to place pointer under graph and click when the "+" symbol appears to expand the graph.